











X-TERRA 305 | 505




Field Guide





-  **Power**
Turns the detector On/Off.
-  **Patterns**
Scrolls through the different Discrimination Patterns.
-  **All Metal**
Toggles between the selected discrimination pattern and the All Metal pattern.
-  **Minus**
Adjusts settings, and scrolls to the left through the discrimination segments.
-  **Menu**
Enters the Menu.
Accesses and scrolls through the detecting settings.
-  **Plus**
Adjusts settings, and scrolls to the right through the discrimination segments.
-  **Pinpoint/Detect**
Pinpoint assists in locating the exact position of a target prior to recovery.
Detect exits menu settings and returns to detection.
-  **Accept/Reject**
Accepts or rejects discrimination segments.
-  **Ground Balance**
Accesses the Ground Balance Menu.





 **Battery**
Indicates remaining power.


 **Headphones**
Indicates headphones are connected.


 **Reject Identification**
Appears when you reject a discrimination segment.


 **Sensitivity**
Indicates that you are in the Sensitivity menu.

 **Ground Balance**
Indicates that you are in the Ground Balance menu.

 **Noise Cancel**
Indicates that you are in the Noise Cancel menu.

 **Threshold**
Indicates that you are in the Threshold menu.

 **Volume**
Indicates that you are in the Volume menu.

 **Tones**
Indicates that you are in the Tones menu.